



EM41x-RDL (Cellular Version)

Radar Distance / Level Sensor

User Guide

Contents

Chapter 1. Preface.....	4
Chapter 2. Product Introduction.....	6
Overview.....	6
Packing List.....	7
Hardware Components.....	7
Main Components.....	7
LED Indicator Description.....	9
Device Dimensions.....	9
Chapter 3. Hardware Installation.....	10
Install the SIM Card.....	10
Fix the Waterproof Cover.....	10
Install the External Antenna (External Antenna Version Only).....	11
Install the Device.....	12
Bracket Installation.....	12
Thread Installation.....	16
Battery Replacement	18
Chapter 4. ToolBox App Configuration.....	19
Access the Sensor.....	19
Access the Sensor Using Bluetooth.....	19
Access the Device Using NFC.....	20
Synchronize Device Time.....	22
Configure Network Parameters.....	23
Configure the Cellular Parameters.....	23
Configure the Application Parameters.....	25
Configure Device Parameters.....	30
Configure Basic Device Parameters.....	30
Configure the Data Storage & Retransmission.....	32

Configure the Calibration Parameters.....	33
Configure the Distance Threshold.....	39
Maintain the Device.....	42
Upgrade.....	42
Configure a Template for Configuration Backup.....	43
Reset the Device.....	45
Chapter 5. Uplink Packets and Downlink Commands.....	47
AWS/MQTT Topics.....	47
Uplink Packets.....	47
Periodically Reported Data Packet.....	49
Alarm Packet.....	49
Downlink Commands.....	51
Commands for General Setting.....	51
Commands for Calibration Setting.....	53
Commands for Threshold Alarm Setting.....	54
Chapter 6. Services.....	57

Chapter 1. Preface

Copyright Statement

This guide may not be reproduced in any form or by any means to create any derivative such as translation, transformation, or adaptation without the prior written permission of Xiamen Milesight IoT Co., Ltd (Hereinafter referred to as Milesight).

Milesight reserves the right to change this guide and the specifications without prior notice. The latest specifications and user documentation for all Milesight products are available on our official website <http://www.milesight.com>

Safety Instruction

These instructions are intended to ensure that user can use the product correctly to avoid danger or property loss. Milesight will not shoulder responsibility for any loss or damage resulting from not following the instructions of this operating guide.



CAUTION:

Injury or equipment damage may be caused if any of these cautions are neglected.

- The device must not be disassembled or remodeled in any way.
- In order to protect the security of the device, please change the device password when first configuration. Default password is 123456.
- The device is not intended to be used as a reference sensor, and Milesight won't should responsibility for any damage which may result from inaccurate readings.
- Do not place the device close to objects with naked flames.
- Do not place the device in where the temperature is below/above the operating range.
- The device must never be subjected to shocks or impacts.

Revision History

Release Date	Version	Revision Content
Nov. 29, 2024	V1.0	Initial version

Release Date	Version	Revision Content
Nov. 28, 2025	V1.1	1. Add NPT Thread Version. 2. Battery pre-installed in the device and removed from packing list.

Chapter 2. Product Introduction

This chapter describes basic product information.

Overview

EM41x-RDL is a non-contact Radar Distance/Level Sensor that adopts Millimeter Wave Radar technology. By measuring millimeter-wave signals at higher frequencies, it provides more stable performance over longer distances, and is less affected by environmental conditions. It can detect the distance between the sensor and liquid of various types, unaffected by temperature, dust, condensate etc. With IP68 waterproof and sealed enclosure, it can withstand the worst environment, while maintaining the measurement accuracy, and does not require routine maintenance.


The cellular version supports multiple application modes to be compatible with IoT platforms.

EM41x-RDL can be used in sewers, rivers, impounding reservoir, storage tanks and high-salt mist environments (including seawater, high-concentration brine), and other locations that require to measure distance and level. It has the following features:

- 8° Radar beam angle can be focused on the target fluid, enabling accurate measurement of liquid level
- Wide measuring range of 0.3m to 12m with small blind zone
- Not affected by dust, condensate, temperature, acoustic noise, etc
- Non-invasive liquid level monitoring, can detect hazardous or non-hazardous liquids
- External antenna or internal antenna versions are optional for various applications
- Built-in 3-axis accelerometer sensor to monitor device tilt status
- Support to check radar-echo curve and one-click diagnostic to calibrate the distance, ensuring the accurate measurement under different environments
- Support blind zone alarm when the ranging results are within the blind zone
- Adopt PVDF material, offering excellent corrosion resistance, wear resistance and compressive strength for harsh environments
- IP68 waterproof design, resistant in fresh water to a maximum depth of 1m for up to 48 hours
- Thread design for common tank installation without extra accessories needed
- Store historical records locally and support retransmission to prevent data loss
- Easy configuration via NFC and Bluetooth
- Support management and OTA upgrade via Milesight Development Platform
- Support multiple network protocols to be compatible with IoT platforms

Packing List

This chapter describes the packing list. You can verify the contents against the following list to ensure all items are present. If any of them is missing or damaged, you can contact your sales representative.




1 × EM41x-RDL Sensor




1 × Mounting Bracket



1 × Bubble Level



1 × Waterproof Tape



4 × Wall Mount
Screw Kits



1 × O-ring Seal



1 × Quick Guide



1 × Warranty Card

Accessories Exclusively for G/NPT Thread Version



1 × G1^{1/2} Nut



1 × NPT1^{1/2} Nut

Accessories Exclusively for External Antenna Version



1 × SMB Magnetic An-
tenna with Screw Kits




1 × Antenna Cable Gland

Hardware Components

Main Components

The following figure shows the main components of the device.



For the description of each component, refer to the following table.

Name	Description
Antenna	External antenna version allows for the attachment of an external antenna to enhance wireless communication range and reliability. The non-external antenna version features an integrated antenna.
NFC area	Allows for wireless configuration through mobile phone NFC.
Radar	Critical component in the ultrasonic system for energy transmission and amplitude transformation.
Battery Compartment	Houses the battery for power supply.
LED Indicator	Indicates the device status.
Metal Contacts	Used for reboot and reset functions by short-circuiting.
SIM Card Slot	Inserts a SIM card to enable cellular network connectivity.

LED Indicator Description


The device has two internal metal contacts and an LED indicator for emergency reboot and reset functions. For the functions of the metal contacts and the corresponding LED indicator status, refer to the following table.

Function	Action	LED Indicator
Power On	Install the New Battery	Lights up for 3s
Power Off	Remove Battery	On → Off
Reboot	Create short circuit with the two metal contacts for over 3s	Blinks Slowly
Reset to Factory Default	Create short circuit with the two metal contacts for over 10s	Blinks quickly
Check On/Off Status	Create short circuit with the two metal contacts within 3s	Light On: device is on.
		Light Off: device is off.


Device Dimensions

The following figure shows the device dimensions (unit: mm).

Internal Antenna Version




External antenna version



Chapter 3. Hardware Installation

This section describes how to install the accessories and device. Before installing accessories, please remove the battery insulation sheet, and the device will automatically power on.




Install the SIM Card

This chapter describes how to install the SIM card.

Steps:

1. Remove the slot cover.
2. Insert SIM card (4FF) as shown in the figure.
3. Replace slot cover back.




Fix the Waterproof Cover


This chapter describes how to fix the waterproof cover.

Steps:

1. Attach the waterproof cover to the device with aligning the two red dots as shown in the diagram, and press waterproof cover firmly with your hand.



2. Screw the top cover clockwise until the edge marks are aligned.




Install the External Antenna (External Antenna Version Only)


This chapter describes how to install the external antenna.

Steps:

1. Install the antenna cable gland as shown in the diagram.



2. Connect the antenna to antenna connector of the device and use an adjustable wrench to tighten the waterproof connector.



Install the Device

Installation Location Requirements:

1. The installation location of the device should avoid strong vibrations, direct sunlight, and exposure to rain or snow.
2. Do not place the device near objects that emit intense heat, strong electromagnetic fields, or radioactive materials.

Maintenance After Device Installation: Anti-static measures need to be taken, such as wiping with a damp cloth to remove any possible static electricity.

Bracket Installation


Preparation:

- Electric drill
- Wrench
- Mounting bracket
- Bubble level
- M4 mounting screws and wall plugs
- G1^{1/2} or NPT1^{1/2} nut
- External antenna accessories (Optional)

Steps:


1. Locate the device installation position.

- Avoid placing the device near any metal objects, water outlets, stairs and other obstacles;
- Please consider the height of the equipment and other factors (such as the height of antenna, the thickness of the manhole cover) to ensure that the equipment does not interfere with normal usage after installation.




2. Adjust Level.

Attach the bubble level to the bracket surface to ensure the bracket is parallel.




3. Fix the mounting bracket.

Drill 4 holes according to the mounting bracket holes. Fix the wall plugs to the wall holes, then fix the mounting bracket to the wall plugs via mounting screws.




Tip:


If the wall is inclined, you can first rotate the bracket assembly 90° clockwise or counterclockwise, and then adjust the horizontal plane up or down as needed based on the actual situation.



4. Adjust Mounting Bracket Angle.


Loosen the two nuts on both the upper and lower tracks of the bracket, adjust the bracket to the appropriate angle, then use a wrench to tighten all six nuts with flat washers.






5. Select the device installation location on the bracket according to the installation height.

Installation Height	Recommend Location
1 ~ 2m	1
2.1 ~ 3m	2
3.1 ~ 6m	3




6. Fix Device.

Place the device onto the mounting bracket, adjust it to an appropriate position, and then tighten it with G1^{1/2} or NPT^{1/2} nut. The torque for tightening the nut with a wrench should not exceed 4 N·m.



7. Fix Antenna (External Antenna Version Only).

The antenna can be secured to the mounting bracket with screws, or it can be fastened to the sewer wall with bolts and screws. Additionally, it can be attached to any metal surface using the magnetic base at the bottom of the antenna.



8. After installation, refer to the [Configure Calibration Parameters](#) to check the tilt status and perform the following installation calibration.

- [Relative Initial Surface](#)
- [Blind Zone Calibration](#)

Thread Installation


Preparation:

- Metric ruler
- O-ring seal
- G1^{1/2} or NPT1^{1/2} nut

Steps:

1. Locate the Device Installation Position.


- Place it away from the tank wall more than 20cm;
- Perpendicular to the measured liquid and with no obstacles between the device and the measured liquid.



2. Fix the device.

The device has G1 $\frac{1}{2}$ " or NPT1 $\frac{1}{2}$ " thread opening to allow it to be screwed into an existing applicable thread opening of a tank. An O-ring is supplied and should be used to ensure a watertight seal.

When the mounting hole on the tank does not match the sensor, an adapter can be installed on the top surface of the tank to mount the sensor. Adapters for different sizes need to be purchased separately. The device should be threaded and screwed firmly onto the adapter to ensure a good seal. The O-ring shown below seals the connection between the adapter and the bottom of the sensor's main enclosure.

3. After installation, refer to the [Configure Calibration Parameters](#) to check the tilt status and perform the following installation calibration.

- [Relative Initial Surface](#)
- [Blind Zone Calibration](#)

Battery Replacement


This chapter describes how to replace the battery when the device runs out of power.

Battery Requirements:

- Power the device by ER34615 Li- SoCl_2 battery. Alkaline battery is not supported.
- Remove battery from the device if it is not used for an extended period.
- Always replace with new battery. Using old batteries may reduce battery life or lead to inaccurate power level calculations.

Steps:

1. Unscrew the top cover counterclockwise.
2. Install the battery, the device will turn on automatically and the LED indicator will turn on for 3s.



Chapter 4. ToolBox App Configuration

The Milesight ToolBox app can be used to configure the device. This chapter describes ToolBox related configuration.

Access the Sensor

After the device is powered on, it can be accessed using NFC or Bluetooth. It is recommended to access the device using Bluetooth for the first time installation and configure device and network parameters.

Access the Sensor Using Bluetooth

This section describes how to access the device using Bluetooth. The device can connect to only one phone via Bluetooth.



Note:

The Bluetooth connection will be terminated if there's no data interaction within 3 minutes. Please reconnect as needed.

Steps:

1. Download Milesight ToolBox app from Google Play or Apple Store.
2. Enable the Bluetooth and location functions on the smart phone.
3. Launch ToolBox.
 - a. Upon first launch, the following page is displayed. Select **Bluetooth** and click **Enter**.


Select read method

Please select the default method to establish a connection with the device. This can be changed later through system settings.


NFC	☐
Bluetooth	☒

Enter →

- b. Upon subsequent launches, Click **Maintenance** on the home page, and then select **Bluetooth**.



4. Click  to scan the devices around and select the target device to connect. The default Bluetooth name is model -XXXXXX (5th to 11 st of device SN) and the default device password is 123456.



5. Enter a new password and click the **Confirm**. Password length: between 8 and 12 characters.



Tip:

It is recommended to change a new password for security.

6. If the device is recognized successfully, the homepage is displayed. For a description of the homepage, refer to the following table.

Item	Description
Basic Information	Shows basic device information and sync the system time.
Setting	Sets the device and network parameters.
	Imports, adds, exports or deletes a template.
	Sets the language, shows NFC positions and checks the version.


Access the Device Using NFC

This section describes how to access the device using NFC.


Steps:

1. Download Milesight ToolBox app from Google Play or Apple Store.
2. Enable the NFC function on the smart phone.
3. Launch ToolBox.

a. Upon first launch, the following page is displayed. Select **NFC** and click **Enter**.




b. Upon subsequent launches, Click **Maintenance** on the home page, and then select **NFC**.



4. (Optional) To locate the NFC detection areas of the phone and the device, click **Can't find the NFC location**.
5. Put the NFC detection area of the phone close to the NFC antenna of the device.

i Tip:
It is recommended to take off the phone case.



6. Click . If the device is recognized successfully, the homepage is displayed.



Troubleshooting:

If read fails, move the phone away and reposition it close to the sensor to try again.

For a description of the homepage, refer to the following table.


Item	Description
Basic Information	Shows basic device information and sync the system time.
Setting	Sets the device and network parameters.
	Imports, adds, exports or deletes a template.
	Sets the language, shows NFC positions and checks the version.

Synchronize Device Time

This section describes how to sync the device time.

Synchronize the Time Manually Through ToolBox APP

1. On the homepage of ToolBox, click **Basic Information**.
2. Click  to synchronize the time.



3. Put the NFC detection area of the phone close to the NFC antenna of device. If the time is synchronized successfully, the following page is displayed.



Sync successfully!

Configure Network Parameters

This section describes how to configure the cellular parameters and the application mode.

Configure the Cellular Parameters

This section describes how to configure the cellular parameters.

Steps:

1. On the homepage, click **Setting** to enter the **Setting** page.
2. Click **Network**. The following page is displayed.

Work Mode

Low Power Mode ▼

APN

Authentication Type

NONE ▼

PIN

RPS Pre-configured ⓘ ☐

3. Configure related parameters as need. For parameter descriptions, refer to the following table.

Parameter	Description
Work Mode	Low Power Mode: the device will power off the cellular module to save power after sending uplinks. Only when the device sends uplinks, it can receive downlink commands.
APN	Access point name for cellular dial-up connection provided by a local ISP. Maximum length: 31 characters.
Authentication Type	Options: NONE, PAP and CHAP.
PIN	PIN code to unlock the SIM. Length: 4-8 characters.
RPS Pre-configured	Enable or disable request a pre-configured profile from Milesight Development Platform or other RPS server.

4. Click **Write** in the lower right corner.

5. (Optional) If the read method is **NFC**, put the NFC detection area of the phone close to the NFC antenna of device. If the read method is **Bluetooth**, please skip to the next step.

6. If the configuration succeeds, the following page is displayed.

Write successfully!



Configure the Application Parameters

This section describes how to configure the application parameters to connect to the servers.

Prerequisites:

- Ensure the device is registered with the network.
- Obtained the server's information.

Steps:

1. On the homepage of ToolBox, click **Setting** to enter the **Setting** page.
2. Click the **Application Mode** and select the service from the **Application Mode** selection box, which includes:

Application Mode	Description
MQTT	Connects to the MQTT broker.
TCP	Connects to the TCP server.
AWS	Connects to AWS IoT Core.
UDP	Connects to UDP server.
Milesight Development Platform	Connects to the Milesight development platform server.

3. Configure related parameters as needed.

- When **MQTT** is selected, the following configuration page is displayed:

General
Application Mode
Calibration
...

Application Mode
MQTT

Connection Status
Disconnected

Broker Address
a3rq97tuej9pqy-ats.iot.us-east-1.amazonaws.com

Port
8883

Client ID
6862F10603200021

User Credentials
☐

TLS
☐

MQTT Topic

Parameter	Description
Broker Address	Fill in MQTT broker address to receive data.
Port	Fill in MQTT broker port to receive data
Client ID	Client ID is the unique identity of the client to the server, it must be unique when all clients are connected to the same server.
User Credentials	
Enable	Enable user credentials.
Username	The username used for connecting to MQTT broker.
Password	The password used for connecting to MQTT broker.
TLS	
Enable	Enable the TLS encryption in MQTT communication.

Parameter	Description
Protocol	Fixed as TLS v1.2.
CA File	Import the CA.crt file.
Client Certificate	Import the client certificate.
Client Key	Import the client key
MQTT Topic	
Uplink Topic	Receive periodic reports, threshold alarms, etc. Default: em/[SN]/uplink
Downlink Topic	Send downlink commands. Default: em/[SN]/downlink

- When **TCP** is selected, the following configuration page is displayed:

Device

Network

General

Application Mode

Calibration

...

Application Mode

TCP

Connection Status

Not Connected

Server Address

Port

Retry Interval (s)

5

Retry Times

1

Parameter	Description
Server Address	Fill in the TCP server address (IP/domain name).
Port	Fill in the TCP server port. Range: 1-65535.
Retry Interval (s)	Device waits before attempting to reconnect to the TCP server after a failed connection attempt.
Retry Times	The number of times that a device will attempt to reconnect to the TCP server after a failed connection attempt.

- When **AWS** is selected, the following configuration page is displayed:

Device

Network

General

Application Mode

Calibration

...

Application Mode

AWS

Connection Status

Disconnected

Keepalive Interval(s)

Server Address

CA File

Client Certificate

Client Key

Parameter	Description
Keepalive Interval	After connected, the device will send heartbeat packet regularly to keep alive. Default: 200 s, Range: 1-3600 s
Server Address	Fill in the AWS server domain name which the data sends to.
CA File	Import the CA.crt file.
Client Certificate	Import the client certificate.
Client Key	Import the client key.

- When **UDP** is selected, the following configuration page is displayed:

The screenshot shows the configuration interface for the ToolBox App. At the top, there are two tabs: 'Device' and 'Network'. Below these, there are three sub-tabs: 'General', 'Application Mode', and 'Calibration', with a menu icon '...' to the right. The 'Application Mode' sub-tab is selected and highlighted with a blue underline. Under 'Application Mode', there is a dropdown menu showing 'UDP'. Below this, there are three input fields: 'Server Address' (empty), 'Port' (containing '80'), and a third field (empty).

Parameter	Description
Server Address	Fill in the UDP server address (IP/domain name).
Port	Fill in the UDP server port. Range: 1-65535.

- When **Milesight Development Platform** is selected, refer to [Connect a Device](#) for details.

4. Click **Write** in the lower right corner.

5. (Optional) If the read method is **NFC**, put the NFC detection area of the phone close to the NFC antenna of device. If the read method is **Bluetooth**, please skip to the next step.
6. If the configuration succeeds, the following page is displayed.



Write successfully!

Configure Device Parameters

This section describes how to configure device parameters.

Configure Basic Device Parameters

This section describes how to configure the basic parameters of the device, which includes:

- Reporting interval
- Scenario Mode
- Measurement Range
- Tank Depth
- Tilt & Distance Switch
- Data Storage
- Data Retransmission
- Device password

Steps:

1. On the homepage of ToolBox, click **Setting** to enter the **Setting** page.
2. In the **General** page, configure the following device parameters as needed.

Parameter	Description
Reporting Interval	Reporting interval of transmitting data to server.

Parameter	Description
	Default: 1440 minutes, range: 30~1440 minutes.
Scenario Mode	Options: General: Suitable for calm liquid surfaces Rainwater Well: Suitable for rainwater well Wastewater Well: Suitable for wastewater well
Measurement Range	The maximum distance between target surfaces and device.
Tilt & Distance Switch	When detecting that the offset angle is greater than 15 degrees, turn off the distance measuring function.
Data storage	Disables or enables data storage. For details, refer to Configure the Data Storage&Retransmission .
Data Retransmission	Disables or enables data retransmission. For details, refer to Configure the Data Storage&Retransmission .
Change Password	Refer to Change the Device Password.

- Click **Write** in the lower right corner.
- (Optional) If the read method is **NFC**, put the NFC detection area of the phone close to the NFC antenna of device. If the read method is **Bluetooth**, please skip to the next step.
- If the configuration succeeds, the following page is displayed.



Write successfully!

Configure the Data Storage & Retransmission


The device supports data storage and data retransmission to ensure data integrity. This section describes how to configure data storage and retransmission.

Export the Local Data

The device supports storing up to 2,000 historical records locally. Data will continue to be saved even when the network is de-activated. However, as the ToolBox App limits data exports to the most recent 14-day period, regular exports are necessary to avoid data loss.

Steps:

1. Sync the time to ensure the data is stored in correct time.
2. On the homepage of ToolBox, click **Setting** to enter the **Setting** page.
3. Enable **Data Storage**.
4. Return to the homepage and click **Maintenance** in the lower right corner.
5. Click **Export**, select the data time range and click **Save** to export data.



Enable Data Retransmission

Data retransmission allows the network server receives all data, even after temporary network outages. The reported format of retransmission data will include timestamps and is different from periodic report data.

Prerequisites: This feature is unavailable in **UDP** mode.

Steps:

1. On the homepage, click **Setting** to enter the **Setting** page.
2. Enable **Data Storage** and **Data Retransmission**.
3. Click **Write** in the lower right corner.
4. (Optional) If the read method is **NFC**, put the NFC detection area of the phone close to the NFC antenna of device. If the read method is **Bluetooth**, please skip to the next step.
5. If the configuration succeeds, the following page is displayed.



Write successfully!



Note:

1. Data retransmission increases the uplink traffic and shortens the battery life.
2. If the device reboots or loses power during data retransmission, it restarts and resends the entire retransmission dataset after reconnecting to the network.
3. If a new network disconnection occurs during an ongoing retransmission, only the data logged during this latest outage will be sent upon reconnection.
4. The default report data retransmission interval is 600s, this can be changed via downlink command.

Configure the Calibration Parameters

This section describes how to configure calibration types. The device supports several calibration types. They can be enabled simultaneously. Please calibrate the device during on-site installation, otherwise, the calibration may not take effect.

Recommended Scenarios for Different Calibration Types:

Calibration Type	Description	When to Use
Numerical calibration	Apply a fixed offset to all distance measurements	Consistent fixed error in measurements
Relative initial surface	Set current surface as reference plane	During device installation to define "Normal" position
Measure outlier calibration	Discard and recalibrate readings beyond set range	When measurements show unrealistic spikes
Blind zone calibration	Detect liquid level in blind zone and trigger alarm	To monitor level entry into non-measurable zone
One-click Diagnosis	Manually select accurate distance from echo curve	Readings mismatch reality (Bluetooth read method only)

Steps:

1. On the homepage of ToolBox, click **Setting** to enter the **Setting** page.
2. Click **Calibration**. The following page is displayed.

Device

Network

General

Calibration

Threshold

Distance 

Current Value(m)

-10

Final Value(m)

0

Calibration Value(m)

10

Relative Initial Surface ⓘ

Setting

Clear

The triaxial angle relative to the initial face is (-°, -°, -°)

Measure Outlier Calibration ⓘ



Blind Zone Calibration ⓘ

Calibrate

3. Configure calibration types.

◦ Numerical Calibration

- Enable **Distance**.
- Enter a value in the **Calibration Value** text box. Value range: -10.000 - 10.000.

Distance 

Current Value(m)

2.618

Final Value(m)

2.818

Calibration Value(m)

0.2

◦ Relative Initial Surface

- a. Click **Setting** to read the triaxial angle relative to the current surface, to adjust the current device position as “Normal”.

Relative Initial Surface ⓘ

Setting Clear

The triaxial angle relative to the initial face is (0.06°, 0.28°, -89.76°)

◦ **Measure Outlier Calibration**

- a. Enable **Measure Outlier Calibration**.
- b. Enter a value in the **Outlier Range** or the **Outlier Value** text box. For details, refer to the following table.

Measure Outlier Calibration ⓘ ☒

Maximum Range: 6 m

Outlier Range(%) ⓘ

Outlier Value(m) ⓘ

Parameter	Description
Outlier Range / %	Value range: 0.1 - 100, Unit: %.
Outlier Value / M	Value range: 0.01 - 10, Unit: m.

◦ **Blind Zone Calibration**



- a. Click **Calibrate**. Please ensure there are no objects in the blind zone during calibration.

Blind Zone Calibration ⓘ

Calibrate

◦ **One-click Diagnosis**

- a. Click **Diagnosis** to show the current Radar Echo Curve.
- If the collected distance has only one value, it means the nearest signal amplitude is equal to the strongest signal.
 - If two values appear, it means one represents the nearest signal amplitude and another represents the strongest signal.



- b. Choose a collected distance value that is closer to the actual distance, and click **Confirm** to finish configuration or click **Refresh** to get a new collected distance.
- c. If the distance value is still not accurate, click **Manual Diagnosis**, the following page is displayed. For details, refer to the following table.

Final Distance 2.937m

Radar Echo Signal Quality ⓘ

10

Algorithm Threshold Sensitivity ⓘ

0.8

Peak Sorting ⓘ

Strongest Peak ▼

Parameters	Description
Radar Echo Signal Quality	If the liquid level has significant foam, numerous foreign objects, or the measurement signal is unstable and the peak is not clear, adjust this value upwards.  Note: The larger the value, the greater the power consumption.
Algorithm Threshold Sensitivity	The device requires only one target to measure. When a large number of targets are detected, the sensitivity can be appropriately decreased; when no targets are detected, the sensitivity can be appropriately increased.
Peak Sorting	According to the radar echo curve and the actual scene situation, the peak with the nearest signal amplitude or the strongest peak can be selected as the effective target.



Troubleshooting:

If “Disabled” appears, reset **Relative Initial Surface** or disable **Tilt & Distance Switch**.

- d. When adjusting parameters, click Refresh Final Distance to confirm the final distance value. Once you’ve obtain the desired final distance value, click the arrow on the upper left corner to return to the home page.
4. Click **Write** in the lower right corner.
5. (Optional) If the read method is **NFC**, put the NFC detection area of the phone close to the NFC antenna of device. If the read method is **Bluetooth**, please skip to the next step.
6. If the configuration succeeds, the following page is displayed.



Write successfully!

Configure the Distance Threshold

This section describes how to configure the distance threshold. The device supports two types of distance threshold alarms.

Distance Threshold Alarm

When current value is over or below the value, the device will report a threshold alarm packet once instantly. Only after the previous alarm is cleared and the threshold is re-triggered, the device sends a new alarm.

General
Calibration
Threshold

Distance
☒

Above(m)

Below(m)

Steps:

1. On the homepage of ToolBox, click **Setting** to enter the **Setting** page.
2. Click **Threshold** and enable **Distance**
3. Configure the following threshold parameters.

Parameters	Description
Above/Below	Distance / Liquid level threshold.
Collecting Interval	The interval to detect distance/liquid level, this should be smaller than or equal to the reporting interval.
Alarm Reporting Times	Alarm packet report times after threshold alarm triggers. Default is 1.
Alarm Dismiss Report	When enabled, the device reports the current value to signal that the alarm has cleared once the reading returns to within the threshold range.

4. Click **Write** in the lower right corner.
5. (Optional) If the read method is **NFC**, put the NFC detection area of the phone close to the NFC antenna of device. If the read method is **Bluetooth**, please skip to the next step.

6. If the configuration succeeds, the following page is displayed.



Write successfully!

Distance Shift Threshold

The device will report an alarm packet when the absolute value of the difference between the current value and the last collected value exceeds the threshold value.

Distance Shifts Threshold 

☒

Distance Shifts Over(m)

Steps:

1. On the homepage of ToolBox, click **Setting** to enter the **Setting** page.
2. Click **Threshold** and enable **Distance Shift Threshold**.
3. Configure the following threshold parameters.

Parameters	Description
Distance Shifts Over	When enabled, the device triggers an alarm if the absolute change in value exceeds the set threshold.
Collecting Interval	The interval to detect distance/liquid level, this should be smaller than or equal to the reporting interval.

4. Click **Write** in the lower right corner.

5. (Optional) If the read method is **NFC**, put the NFC detection area of the phone close to the NFC antenna of device. If the read method is **Bluetooth**, please skip to the next step.
6. If the configuration succeeds, the following page is displayed.



Write successfully!

Maintain the Device

This section describes how to maintain the device.

Upgrade




Important:

This device only supports upgrading via Bluetooth mode.

This chapter describes how to upgrade the device. Any operation on ToolBox is not allowed during upgrading, otherwise the upgrading will be interrupted, or even the device will break down.

Steps:

1. Download firmware from [Milesight official website](#) and save it to the smart phone.
2. Launch ToolBox and click **Maintenance** in the lower right corner of the homepage.
3. Click **Upgrade** to import firmware and upgrade the device.
4. Click **Upgrade** to upgrade the device.




Configure a Template for Configuration Backup

This device supports configuration backup, which enables quick and easy batch configuration. This function only applies for devices of the same model.


Set a Template

Steps:

1. On the homepage of ToolBox, click . The **Template** page is displayed.
2. Click **Add Template** in the bottom.
3. Click **Save** in the upper right corner. The **Template Name** page is displayed.




4. Click **Confirm** to save the current configuration as a template. The following page is displayed.



Write the template configuration to the target device

Steps:

1. Click the saved template. Caution: Do not select the template.




2. In the displayed page, click **Write** in the bottom and put the NFC detection area of the phone close to the NFC antenna of the target device. If the configuration is written to the target device, the following page is displayed.



Write successfully!

Export and Delete a Template

1. Select the checkbox of the target template as shown in the following figure.




2. Click **Export** to export this template as a JSON format file and save it to the smart phone.
3. Click **Delete** and Confirm to delete this template from ToolBox.

Reset the Device

This section describes how to reset the device in ToolBox. Additionally, the device supports hardware reset. See [LED Indicator Description](#) for details.

Steps:

1. On the homepage of ToolBox, click **Maintenance** in the lower right corner. The **Maintenance** page is displayed, see the following figure.



2. Click **Reset**.
3. In the displayed dialog box, click **Confirm**.
4. Put the NFC detection area of the phone close to the NFC antenna of the device. If the device is successfully reset, the following page is displayed.



Write successfully!

Chapter 5. Uplink Packets and Downlink Commands

The device uses the standard Milesight IoT payload format based on IPSO. This chapter describes the uplink data packets and downlink commands supported by the device. They are all structured in the following format, the Data field should follow **little endian**:

Channel 1	Type 1	Data 1	Channel 2	Type 2	Data 2	Channel 3	...
1 Byte	1 Byte	N Bytes	1 Byte	1 Byte	N Bytes	1 Byte	...

All explanations and examples in this document are based on the HEX format. For all the Milesight IoT decoder examples, refer to the files available on <https://github.com/Milesight-IoT/SensorDecoders>.

AWS/MQTT Topics

When the device is connected to AWS/MQTT server, the bi-directional communication uses different default topics. MQTT topics support to be changed as required.

Topic	Content
em/[SN]/uplink	Receive periodic reports, threshold alarms, etc.
em/[SN]/downlink	Send downlink commands

Uplink Packets

This section describes the uplink packets reported by the device. They can be checked on the servers.

Start	ID	Packet Length	FLAG	TSL Ver-sion	Reserved	Software Version	Hardware Version
02	0101	2 Bytes	00	0101	01	4 Bytes	4 Bytes
SN	IMEI	IMSI	ICCID	Signal	Data Length	Data1	...
16 Bytes	15 Bytes	15 Bytes	20 Bytes	1 Byte	2 Bytes	N Bytes	...

Example:

02 0101 005D 00 0101 01 30313031 30313031 36373439443139303534363930303331 383638353038303634383037333530 343630303433323234323133313130 3839383630343132313032323730303632383537 09 0007 01756404823B01	
Type	Content
Start	02
ID	0101
Packet Length	00 5d=93 bytes
FLAG	00
TSL Version	0101=V1.1
Reserved	01
Software Version	30 31 30 31 => 0101=V1.1
Hardware Version	30 31 30 3 =1> 0100=V1.1
SN	36373439443139303534363930303331 =>6749D19054690031
IMEI	383638353038303634383037333530 =>868508064807350
IMSI	343630303433323234323133313130 => 460043224213110
ICCID	3839383630343132313032323730303632383537 => 89860412102270062857
Network Signal	09=>9 asu
Data Length	0007=>7 Bytes
Data	Format: Channel + Type + Data, see details in below tables  Note: the Data field should follow little-endian

Periodically Reported Data Packet

The device reports a sensor data packet at a configured interval.

Packet description:

Item	Channel	Type	Byte	Description
Battery Level	01	75	1	UINT8, Unit: %
Distance/Liquid Level	04	82	2	INT16, Unit: mm
Device Position	05	00	1	00: Normal, 01: Tilt (horizontal offset angle $\geq 15^\circ$)
Radar Signal Strength	06	c7	2	INT16/100, Unit: dBm

Example:

017562 0482aa0c 06c70303 050000		
Channel	Type	Value
01	75	Battery: 62=>98%
04	82	Distance/Liquid Level: aa0c => 0caa =>3242 mm
06	c7	Radar Signal Strength:03 03=> 771/100=7.71dBm
05	00	Device Position: 00 = Normal

Alarm Packet

The device reports the following two types of alarm packets.

Packet description:

Item	Channel	Type	Byte	Description
Distance/Liquid Level Alarm	84	82	3	Byte 1-2: Distance/Liquid Level, INT16, Unit: mm Byte 3: 01-Alarm; 00-Alarm dismiss

Item	Channel	Type	Byte	Description
Distance/Liquid Level Shifts Threshold	94	82	5	Byte 1-2: Distance/Liquid Level, INT16, Unit: mm Byte 3-4: Distance/Liquid Level Shifts, INT16, Unit: mm Byte 5: 02
Blind Zone	b4	82	3	Byte 1-2: Distance, INT16, Unit: mm Byte 3: • 00-Alarm dismiss • 01-Alarm ◦ No target within 30cm, report distance as fffd ◦ Have target within 30cm, report the distance • 02-Cannot collect the target, report distance as fffd • 03-Sensor Abnormal, report distance as ffff

Example 1:

Threshold Alarm: report when distance/liquid level reaches the threshold.

8482 c827 01 9482 c827850c 02		
Channel	Type	Value
84	82	Distance/Liquid Level: c8 27 => 27 c8 =10184mm = 10.184m Alarm Status: 01= Alarm
94	82	Distance/Liquid Level Shifts Threshold: c8 27 => 27 c8 =10184mm = 10.184m, 85 0c => 0c 85=3205mm = 3.205m

8482 c827 01 9482 c827850c 02		
Channel	Type	Value
		02=Alarm

Example 2:

Blind Zone Alarm: report when the target value reaches the blind zone.

b482 ac00 01		
Channel	Type	Value
b4	82	ac 00 => 00 ac = 172mm = 0.172m 01=calibrated distance

Downlink Commands

Downlink commands can be used for remote control of device through a network server.

**Note:**

The device can only receive downlink commands within the 8s after sending uplink packets.

Commands for General Setting

The device supports multiple commands for general setting.

Command description:

Item	Channel	Type	Byte	Description
Reboot	ff	10	1	ff
UTC Time Zone	ff	bd	2	INT16/60
Clear History Data	ff	27	1	01
Query Device Status	ff	28	1	01
Data Storage	ff	68	1	00: Disable, 01: Enable

Item	Channel	Type	Byte	Description
Data Re-transmission	ff	69	1	00: Disable, 01: Enable
Data Retransmission Interval	ff	6a	3	Byte 1: 00 Byte 2-3: UINT16, Unit: s, Range: 30~1200, Default: 600
Reporting Interval	ff	8e	3	Byte 1: 00 Byte 2-3: Reporting Interval, UINT16, Unit: min, Range: 30~1440
Scenario Mode	f9	12	1	00 = General Mode; 01 = Rainwater Well Mode; 02 = Wastewater Well Mode
Measurement Range	ff	1b	5	Byte 1: 00 = General Mode; 01 = Rainwater Well Mode; 02 = Wastewater Well Mode; Byte 2-3: 0000 Byte 4-5: Max. Measuring Range, UINT16, Unit: mm
Set Tilt & Distance Switch	ff	3e	1	01 = Enable; 00 = Disable

Example 1:

Reboot the device.

ff10ff

Example 2:

Set reporting interval as 30 minutes.

ff8e1e00		
Channel	Type	Value
ff	8e	1e00=>001e=30 minutes

Example 3:

Set the time zone as UTC-4.

ffbd10ff		
Channel	Type	Value
ff	bd	10 ff => ff 10 = -240/60=-4

Example 4:

Set the device as Wastewater Well mode.

f912 02		
Channel	Type	Value
f9	12	02 = Wastewater Well Mode

Commands for Calibration Setting

The device supports multiple commands for calibration setting.

Command description:

Item	Channel	Type	Byte	Description
Device Calibration	ff	2a	1	01-Blind Zone Calibration
Distance Calibration	ff	ab	3	Byte 1: 01-Enable; 00-Disable Byte 2-3: Calibration Value, INT16, Unit: mm

Item	Channel	Type	Byte	Description
Recollecting of Measure Out-lier Calibration	ff	1c	2	Byte 1: Recollecting Times, UINT 8, Range: 1~3 Byte 2: Recollecting Interval, UNIT 8, Unit: s, Range: 1~10
Radar Echo Signal Quality	f9	14	2	INT16, Range: -10~35
Algorithm Threshold Sensitivity	f9	15	2	INT16/10, Range: 0.1~1
Peak Sorting	f9	16	1	00-Nearest Peak; 01-Strongest Peak

Example:

Select the strongest peak as the effective target.

f91601		
Channel	Type	Description
f9	16	01 = Strongest Peak

Commands for Threshold Alarm Setting

The device supports the threshold alarm setting command.

Command description:

Item	Channel	Type	Byte	Description
Collecting Interval	f9	39	2	Unit: min, Range: 1~1440
Set Threshold Alarm	ff	06	9	Byte 1: • Bit2~Bit0: ◦ 000-disable

Item	Channel	Type	Byte	Description
				◦ 001-below ◦ 010-over ◦ 011-within ◦ 100-below or over ◦ 101-Distance shifts over • Bit5~Bit3: ◦ 001-Distance threshold alarm ◦ 010-Distance shifts threshold alarm • Bit6: 0 • Bit7: ◦ 0-disable threshold dismiss report ◦ 1-enable threshold dismiss report Byte 2-3: Min. Value, INT16, Unit: mm Byte 4-5: Max. Value or distance shifts value, INT16, Unit: mm Byte 6-9: 00000000
Alarm Report- ing Times	ff	f2	2	UINT16, Range: 1~1000, Default: 1

Example:

When the distance is below 1m or over 10m, the sensor will send threshold alarm.

ff06 8c e803 1027 00000000		
Channel	Type	Description
ff	06	8c=10 001 100: 100=below or over 001=Distance threshold alarm 10=enable threshold dismiss report

ff06 8c e803 1027 00000000		
Channel	Type	Description
		Min: e8 03 => 03 e8 = 1000 mm = 1m Max: 10 27 => 27 10 = 10000 mm=10m

Chapter 6. Services

Milesight provides customers with timely and comprehensive technical support services. End-users can contact your local dealer to obtain technical support. Distributors and resellers can contact directly with Milesight for technical support.

Technical Support Mailbox: iot.support@milesight.com

Online Support Portal: <https://support.milesight-iot.com>

Resource Download Center: <https://www.milesight.com/iot/resources/download-center/>

MILESIGHT CHINA

TEL: +86-592-5085280

FAX: +86-592-5023065

Add: Building C09, Software Park Phase III, Xiamen 361024, Fujian, China